




DRAGONLOCK



The clip slots on the sides of tiles can be filled with a plug when not in use. Simply insert the plug as shown.



The plugs come in both smooth and woodgrain versions.



To remove a plug, insert a thin tool (like tweezers) behind it and gently push forward.